
Digital Thermometer and Hygrometer LT-2 Operation Instructions

General features:

LT-2 is a cabinet and exquisite ultra thin digital thermometer and hygrometer. It could simultaneous display of temperature and humidity, memorize the Max. and Min. temperature and humidity values, switch between °C and °F. Suitable for household, green house, office and labs.

Technical parameters:

- ◇ Temperature measuring range: $-5^{\circ}\text{C} \sim +50^{\circ}\text{C}$ ($23^{\circ}\text{F} \sim 122^{\circ}\text{F}$)
- ◇ Humidity measuring range: 30%RH~90%RH
- ◇ Resolution: 1
- ◇ Accuracy: temperature: $\pm 1^{\circ}\text{C}$;
- ◇ Power supply: DC3.0V, one button cell CR2032

Operation instructions:

- ◇ Power on: Place the switch to “ON”, LCD displays full screen and then displays the measuring temperature value for 2 sec.
- ◇ °C/°F: switch between °C and °F.
- ◇ Min: Display the memorized Min. temperature and humidity values.
- ◇ Max: Display the memorized Max. temperature and humidity values.

Notice:

- ◇ LCD displays faintly when the button cell is in low power. Please replace it.
- ◇ Battery replacement: Pull out the battery box and put into one battery with right polarity, then push into the battery box.